

**2005 - 2010 Ford Mustang Convertible Wind Blocker
Fitting Instructions**

INSTALLATION AND REMOVAL OF YOUR WINDSTOP



REMOVE WINDSTOP FROM STORAGE BAG
AND PLACE OVER REAR TRIM PANELS
AS SHOWN



ON EACH SIDE OF THE CAR,
TAKE TIE-DOWN STRAP AND HOOK
UNDER BOTTOM OF TRIM NEXT TO REAR SEAT

HERE IS THE BOTTOM OF THE TRIM WHERE
TO HOOK THE TIE-DOWN STRAP



ONCE HOOKED UNDER, USE THE VELCRO
STRIP TO CINCH THE TIE-DOWN STRAP
TIGHTLY SO THAT THERE IS NO MOVEMENT
IN THE WINDSTOP



THE CONVERTIBLE TOP CAN BE RAISED OR
LOWERED WITH THE WINDSTOP IN PLACE